

Purpose

MOD AIADJ sets the AI adjustment factor at the beginning of the run whenever the date specified falls within the run period. Operations API-CIN, API-MKC and API-CONT contain the AIADJ factor.

In Operations API-CIN and API-MKC the AI value is adjusted by the factor.

In Operation API-CONT the AIXW and AIXD parameters are adjusted. Thus the full adjustment is only applied to the AI value when API=0.0. The amount of the adjustment decreases as API increases.

This is a permanent change to the value stored in the Forecast Component parameter file.

Format

Use Format B3 with one date on the command card.

```
.AIADJ date [ FGROUP ]  
identifier value [ / opname ]
```

where date is the date which must be greater than or equal to
Technique STARTRUN
value is the AI adjustment factor

Example

In this example AI adjustment are input for several Segments. If the date specified falls within the run period then the AI adjustment factor is permanently changed in the parameter file.

```
.AIADJ 1108  
GRNM5-NULM5 .5  
NWUM5-RAPM5 -1.0  
RPDM5 -1.5 / RPDM5  
MNKM5 1.
```